


# LED String Work Light

## FIXTURE INSTALLATION

LED String Work Light

SWL-60W-50

Important: Read all instructions in order to ensure safety and proper installation.



## MAINTENANCE

- Do not modify this fixture. Any modifications may render the product unsafe and void warranty.
- This product is suitable for wet locations.

### Limited Warranty

The warranty applies to the product from the original date of purchase for five (5) years against manufacturing defects. The owner must provide a copy of the original proof of purchase. The manufacturer's obligation under this warranty is limited to repairing or replacing the component. It is not related in any way to the cost of the connection, the installation of the replacement parts or cost of transport.

# INSTALLATION GUIDE

1. Before installing, please make sure that the lamps show no signs of damage, the wire insulation is intact, with no bare wire exposed.
2. Install the LED String Work Lights using the carabiner clips pre-installed on each lamp.
3. Plug in the LED String Work Light into a grounded receptacle.

**NOTE:** Please keep LED String Work Light away from any corrosive substances.